


# Setting Up Thermostat Mapping




1

Go to an HVAC (Controlled) equipment.



2

Select the Thermostat from 'Tstat Mapping' dropdown.



3

Click **Save** and the process has been completed. You can then go in and edit or delete this setting by clicking the 3 vertical dots in the top right corner of the Thermostat Mapping section.

