


Modifying Thermostat Settings



1

Click the Devices tab within a Site menu, and select the Equipment/Thermostat that needs adjustment.


Click the **"Mapped Equipment"** button.



2

Click the 3 vertical dots in the top right corner of the Controls: HVAC section, then click **"Edit Controls"**.

Basic thermostat settings and Schedules can be edited here. Click **"Save"** once adjustments have been made.



3

Click the **"Auto"** button on the bottom right and then select the **"Confirm"** button to finalize set points.

